

NOTES:

- 1. PRESSURE LATERAL MUST BE A MINIMUM OF 4.0' DEEP.
- 2. SEE PIPE BEDDING STANDARD DETAIL FOR BEDDING REQUIREMENTS.
- 3. BACKFLOW PREVENTER MUST BE CONSTRUCTED WITH A TRUE UNION BALL CHECK VALVE EQUAL TO THOSE MANUFACTURED BY SPEARS MANUFACTURING.
- 4. TYPICAL FORCE MAIN SHALL BE SDR 21 OR DR 11 HDPE WITH A 200PSI, RATING.

PRESSURE LATERAL CONNECTION

SPRING - BENNER - WALKER

JOINT AUTHORITY

SHEET

25